

ELITE Terminal Printer Cleaning

- **DO NOT WAIT FOR A PRINTING ISSUE TO CLEAN THE PRINTER - BECAUSE IT IS TOO LATE**
- **CLEAN PRINTER EACH TIME THE PAPER ROLL IS CHANGED OR ONCE A WEEK – WHICHEVER COMES FIRST**
- **TERMINAL CAN BE POWERED ON DURING CLEANING**

Click below for a video of the cleaning process, and review the written instructions that follow.


[ELITE Terminal Printer Cleaning Video](#)

Remove the paper roll and clear any paper and dust particles from inside the printer.

Clean the **PRINTER HEAD** (*Image 1*)

- if a ticket was just printed, wait 20 seconds before cleaning as the printer head could be hot
- clean across the entire width of the **PRINTER HEAD** using a cloth dampened with clean water and then dry with a lint-free cloth

Image 1



ELITE Terminal Printer Cleaning

- Clean the black **PAPER PLATEN ROLLER, WHITE PRINTER ROLLERS** and **CUTTER** with a dry lint-free cloth (*Image 2*)
- Clean the **PAPER CABIN** (*Image 3*),
 - Clean the paper cabin using a cloth dampened with clean water and then dry with a lint-free cloth





Image 3

